

Guardian QR700-G2™

User and Installation Manual



St. Louis, MO
Customer Service: (866) 240-1870 • Technical Support: (866) 956-1211 • Fax: (314) 595-6999
For listing information visit our website www.pottersignal.com

Document 5409363-Rev. A
07/26

Table of Contents

Contents

CHAPTER 1: INTRODUCTION & OVERVIEW	4
1.1 Product Overview	4
1.2 Package Contents	4
1.3 Additional Items Needed.....	4
1.4 Key Features & Benefits.....	4
1.5 Optional Accessories	4
1.6 How it Works.....	5
1.7 Single vs. Multiple Carrier Operation.....	5
1.8 A Word About Safety.....	5
CHAPTER 2: BDA INTERFACE & CONNECTIONS.....	6
2.1 Guardian QR700-G2 BDA Interface Overview	6
A7 USB on top of BDA	6
2.2 RF Interfaces (A1 & A6).....	7
2.3 Power Interface for 110VAC or UPS Output (A5)	7
2.4 RS-232 Interface for UPS (A3)	8
2.5 Alarm I/O Interface (A2).....	9
2.6 Ethernet Interface (A4)	11
2.7 USB Interface	11
2.8 Alarm LEDs (A8)	12
2.9 DC20-32V Interface (A9)	13
CHAPTER 3: PLANNING THE INSTALLATION.....	14
3.1 Installation Overview	14
3.2 Exterior Antenna	15
3.3 Interior Antennas	15
3.4 Antenna Separation.....	16
3.5 Locating the BDA.....	17
3.6 Accessories	17
3.7 Need Help?.....	17
CHAPTER 4: INSTALLATION	18
4.1 Soft Installation	18
4.2 Exterior Antenna	18
4.3 Interior Antennas	19
4.4 Mounting the BDA.....	20
CHAPTER 5: Configuration & Testing	21
5.1 Powering on the BDA	21
5.2 DIP Switch Configuration.....	21
5.3 Band LED Conditions	22
5.4 Testing & Troubleshooting	23
CHAPTER 6: Alarm Interface, Definitions & Conditions.....	24
6.1 Summary Alarm Trigger Conditions.....	24
6.2 Alarm LED Descriptions.....	25
CHAPTER 7: Sentry Configuration & Monitoring	26
7.1 Sentry Software Introduction	26
7.2 Software Installation	26
7.3 Hardware Installation.....	29
7.4 Configuring the Booster System.....	31
CHAPTER 8: Safety And Compliance.....	35
8.1 IC Compliance	35
8.2 A Word About Safety.....	35
CHAPTER 9: SPECIFICATIONS.....	36
CHAPTER 10: WARRANTY	37
10.1 Warranty Periods.....	37
10.2 Three-Year Product Warranty	37
10.3 Limitations of Warranty, Damages and Liability.....	37

CHAPTER 1: INTRODUCTION & OVERVIEW

1.1 Product Overview

The Guardian QR700-G2 significantly improves the quality of crucial first-responder communications in buildings with weak signal strength. For optimal coverage, the BDA uses built-in safeguards to eliminate interference to public-safety networks. Plus, the Guardian QR70-G2 offers the industry's best three-year warranty.

The Guardian QR700-G2 is enclosed in a NEMA-4 compatible housing, and enhances the coverage area of first responder radio communications for in-building applications. It is equipped with bi-directional paths (down-link & up-link) for transmit and receive frequencies, and advanced filtering technology for low-noise amplification of signals.

1.2 Package Contents

Your BDA box contains the following items:

- Guardian QR700-G2 Bi-directional Amplifier
- NEMA-4 rated housing
- Mounting kit
- AC power supply
- Wall anchors

1.3 Additional Items Needed

The Guardian QR700-G2 needs the following additional components for a complete install:

- External antenna
- Lightning protector
- Cable splitter if installing multiple antennas
- Sufficient COAX-PL 1/2 inch RF cable
- Multiple antennas (omnidirectional domes and/or panels by Potter)
- Grounded surge suppressor for DC power supply

1.4 Key Features & Benefits

- Suitable for large areas up to approximately 80,000 square feet depending on outside signal strength.
- Extends signals in areas with poor coverage due to geographical location and/or building design.
- Powerful in-building BDA with 25 dB of adjustable gain level.
- NEMA-4 rated amplifier housing. No additional NEMA enclosure required.
- Meets Chapter 24 Emergency Communications System of NFPA 72
- Integrated 7-pin alarm and UPS port for 24 VDC external battery backup input.
- Power control maintains maximum output power at 27 dBm Downlink / 24 dBm Uplink.
- Automatic oscillation detection and protection system powers down the BDA to prevent harmful radio interference.
- Automatic gain control (AGC).
- Features built-in Potter Sentry remote-monitoring system with Ethernet port.

1.5 Optional Accessories

Potter provides many optional features and accessories for the Guardian QR700-G2 Amplifier. See table below:

Splitters and Couplers	
TQ-SPLIT-698-2700-2	Wide Band 2 Way Splitter
TQ-SPLIT-698-2700-3	Wide Band 3 Way Splitter
TQ-SPLIT-698-2700-4	Wide Band 4 Way Splitter
C TQ-COUP-698-2500-6	-6dB Coupler
TQ-COUP-698-2500-10	-10dB Coupler

Introduction & Overview

Outdoor Antenna Options	
230W	Wide Band Yagi Directional 50 ohm Antenna 10 to 11dBi gain (includes mounting kit, 698-960 & 1710-2700 MHz)
Inside Antenna Options	
222W	Wide Band Dome 50 ohm Antenna - 3 to 4dBi (includes mounting kit, 698 -2700 MHz)
530W	Wide Band Panel 50 ohm Antenna - 7 to 10dBi (includes mounting kit, 698-2700 MHz)
Plenum Cable	
COAX-PL-FT	1/2" Coaxial Cable - Plenum Rated / Low Loss / Air Dielectric / 50 Ohm
Accessories & Connectors	
LP-N	Lightning Protector
ATNR-5	5 dB RF Attenuator
ATNR-10	10 dB RF Attenuator
ATNR-20	20 dB RF Attenuator
CN-09	N Male Crimp Connector, 400 and Plenum Cable
CN-12	N Male to N Male Connector
CN-16	N Male Connector, 600 Cable
Guardian-BBU-10	BDA Power Supply, 25V, 10A, 55/110- AH
Guardian-BBU-20	BDA Power Supply, 25V, 20A, 110/150 AH
Mount-Pole	L Bracket mount with U bolt hardware for donor antenna mount to J-bar
Mount-JBar	Steel 1 inch J-Bar mount for donor antenna. Antenna mount not included

1.6 How it Works

The Guardian QR700-G2 amplifies signals that reach a building from the nearest radio tower, and from radios inside the building going back to the tower. This compensates for weak reception caused by distance, topography, building structure, etc. The BDA receives the signal from an outside antenna, amplifies that signal, and then rebroadcasts it via antenna(s) inside the building, where it can then be picked up by radios inside. In the reverse direction, interior antennas also pick up signals coming from radios, where they are amplified by the BDA, and then passed to the exterior antenna for rebroadcast back to the tower.

1.7 Single vs. Multiple Carrier Operation

Potter's rated output power of this equipment is for single-carrier operation. It is recommended that you factor in loss when dealing with multiple carrier signals. We suggest 3 to 5 dB loss factor.

1.8 A Word About Safety

Follow all safety precautions in this manual. This information is designed to prevent personal injury, equipment malfunction, and/or radio interference. You are responsible for ensuring a safe installation.

Your installation may require working in high locations such as roofs and/or ladders. Follow applicable safety regulations and best practices to avoid falling. Take care not to drop objects from any high area. Cordon off ground areas directly below the section of roof you are working on, or below your ladder whenever possible.


In addition, as a qualified installer, you are responsible for knowing and following all applicable codes and regulations and for obtaining all required permits and inspections.

Always use appropriate personal protective equipment such as goggles, gloves, hard hat, etc. as needed, and as required.



WARNING: FAILURE TO EXERCISE CAUTION WHEN WORKING IN HIGH AREAS COULD CAUSE A FALL AND PERSONAL INJURY.

2.1 Guardian QR700 BDA Interface Overview



Interface Type	Definition	Description
A0	Grounding lug	Grounding lug
A1	OUTSIDE	N Female for OUTSIDE cable and antenna
A2	ALARM I/O	To Fire Department Control Box.
A3	RS-232	To UPS, Reserved for communication with UPS
A4	ETHERNET	Remote Monitoring Ethernet Port
A5	POWER 110VAC	Connect to 110VAC or 110V of UPS output
A6	INSIDE	N Female for INSIDE cable and antenna
A7	USB	USB port found on top of the BDA. Used to initialize the network connection devices
A8	Alarm LEDs	See Chapter 6 for details
A9	DC POWER INPUT	Connect to DC 24V, 3A BBU input

2.2 RF Interfaces (A1 & A6)



A1 — N-type Female for OUTSIDE cable and antenna



A6 — N-type Female for INSIDE cable and antenna


2.3 Power Interface for 110VAC or UPS Output (A5)




A5 —Male 110VAC on BDA



Female 110v Connector Used for External Power Source (110VAC or UPS Output)



Male 110v (A5) Pinout Diagram



Female 110v Pinout Diagram

Pin Number	Definition	Full Name	Color	Note
1	L	Live Wire	Black	
2	N	Neutral Wire	White	
3	E	Earth Wire	Green	


2.4 RS-232 Interface for UPS (A3)




Female RS-232 Connector on BDA



Male RS-232 Connector
Used for UPS Communications



Female RS-232 (A3) Pinout Diagram



Male RS-232 Connector Pinout Diagram

Pin Number	Definition	Full Name	Color	Note
1	RS-232-RXD	RS-232 Receive Data	NG	External connection to TXD of UPS
2	RS-232-TXD	RS-232 Transmit Data	NG	External connection to RXD of UPS
3	NC	No connection	NG	
4	NC	No connection	NG	
5	GND	Ground	NG	


2.5 Alarm I/O Interface (A2)




Female Alarm Connector on BDA (A2)



Male Alarm Connector for Transfer to Fire Department Control Box



Female Alarm (BDA) Connector Pinout Diagram



Male Alarm Connector Pinout Diagram

Pin Number	Definition	Color
1	External Alarm IN 1	Black
2	External Alarm IN 2	Red
3	Dry Contact VSWR Alarm (Outside Antenna)	White
4	Dry Contact RF Module Summary Alarm (Normally Closed)	Green
5	External IN GND	Orange
6	Dry Contact VSWR Alarm (Inside Antenna)	Blue
7	Dry Contact RF Module Summary Alarm (Normally Closed)	Yellow

2.6 Ethernet Interface (A4)



Female Ethernet Port (RJ-45) on BDA
Hidden Under Yellow Cap



Male Ethernet Connector
For Data Transfer


2.7 USB Interface

The USB connector is on top of the Guardian unit, below the DIP switches, as shown below.



BDA Interface & Connections

As shown, the NEMA housing must be open to gain access to this port. The interface is used to initialize network connections using a computer. Be sure to unplug the USB cable after the network initialization is completed.



2.8 Alarm LEDs (A8)

	Status	Description	Note
POWER	Green ON	Normal	
	OFF	Missing Power	
ALARM1	Red ON	NO	Reserved for: Battery undervoltage Power AC off Battery charge
	OFF	Normal	
ALARM2	Red ON	RF Module Summary: Over-current Osc alarm Over-power	
	OFF	Normal	
ALARM3	Red ON	VSWR Alarm	
	OFF	Normal	


2.9 DC20-32V Interface (A9)




Female Connector for DC 20-32V DC



Male Connector for DC 24V DC (A9)



Female used to connect to 110VAC or 110V of UPS output



Male pinout on BDA (A9)

Pin Number	Definition	Full Name	Color	Note
1	DC-	DC Negative pole	Black	
2	DC+	DC Positive pole	Red	

CHAPTER 3: PLANNING THE INSTALLATION

3.1 Installation Overview

Typically, a BDA installation follows these steps:

1. Decide what type of exterior antenna to use, and where to mount it. You will use either an omnidirectional antenna, mounted vertically, or a directional Yagi antenna, pointed directly at the radio tower (line of sight). The antenna will normally be mounted on the wall or roof of the building with the strongest signal. A grounded lightning protector is required between the exterior antenna and the BDA.
2. Decide where to mount the interior antenna(s), being sure to take separation requirements into account. Long, narrow spaces benefit most from directional flat-panel antennas, while more square spaces benefit more from omnidirectional dome antennas.
3. Decide where to mount the BDA. This should be in a secure indoor location near a grounded power source.
4. Decide where to route the cables between the exterior antenna and the BDA and between the BDA and interior antennas.
5. Install the antennas as described in their respective Installation Manuals.
6. Route the cables to the BDA location.
7. Install the BDA as described in this manual.
8. Power on the BDA and perform configuration and testing explained in Chapter 5.

Important Installation Safety Precautions:



CAUTION: FAILURE TO PROPERLY INSTALL A LIGHTNING PROTECTOR CAN RESULT IN DAMAGE TO THE BDA, ANTENNAS, AND WIRING.


- Some components may be heavy and/or bulky. Always use proper lifting and carrying techniques when handling components, especially when working on a ladder, roof, or other area with a fall hazard.
- The exterior antenna must not be co-located or operating in conjunction with any other antenna.
- Always use a properly installed Potter lightning protector between the exterior antenna and the BDA.
- Always power off the BDA before working on the roof of the building, or anywhere in close proximity to the external antenna.
- Allow at least 24 inches (60cm) of separation between interior antennas and humans or animals.
- Allow at least 24 inches (60cm) of separation between exterior antennas and all persons.
- Comply with all antenna separation requirements to prevent signal oscillation.



CAUTION: SIGNAL OSCILLATION CAN CAUSE RADIO INTERFERENCE WITH RADIO TOWERS AND RESULT IN CIVIL AND/OR CRIMINAL PENALTIES.

3.2 Exterior Antenna

You may use either an omnidirectional antenna that covers flat areas with no obstructions or a directional Yagi antenna to point directly at the tower. The omnidirectional antenna receives and transmits signals over a horizontal 360-degree circle. The Yagi antenna receives and transmits signals over a focused area and must be aimed directly (line of sight) toward the radio tower that provides the strongest signal to the building. Generally the Yagi antenna is recommended to assist in maintaining good isolation between the indoor and outdoor antennas.




The exterior antenna and mast (if any) must be mounted in a location that meets all of the following criteria:

- Best signal strength.
- Not co-located with other antennas or used in conjunction with other antennas.
- Away from all power lines.
- At least 6 ft. from lightning rod antennas.
- At least 24 in. from any person.

These distances are general guidelines only. Refer to the applicable building and electrical codes in your area to determine specific local requirements.

3.3 Interior Antennas


You may use any combination of omnidirectional (dome) and/or directional (flat panel) interior antennas to obtain balanced signal strength through-



out the structure.

Dome antennas provide 360-degree hemispherical coverage suitable for mostly square areas, while flat panel antennas provide a focused zone of coverage suitable for long narrow areas. The example above uses two dome antennas and one panel antenna to provide full coverage

Keep in mind that floor structures in multistory buildings can cause significant signal loss, which means that you may need to install interior antennas on more than one floor. Here is an example of a multistory installation:



Note: You may not need antennas on every floor of a multistory building, depending on factors such as building material, BDA gain, etc.

3.4 Antenna Separation

Proper antenna separation prevents signal oscillation (feedback) that can interfere with the radio tower. Separation is measured in a straight line from the exterior antenna to the closest interior antenna. The closest allowable distance depends on a number of factors, such as BDA gain level, building material, etc. Recommended separation distances are:


Amplifier gain	Min. separation (ad)
40 dB	5'-6'
45 dB	15'-20'
50 dB	50'
55 dB	60'
65 dB	75-80'
70 dB	100'
75 dB	100'-120'
80 dB	120'-180'

Vertical separation is more important than horizontal separation. If you are unable to obtain the required separation horizontally, try raising the exterior antenna. You may also try reducing the BDA gain as described in Chapter 5 of this manual.

Antenna Safety Precautions:

You can mix and match dome and directional antennas as needed to obtain proper coverage throughout the building or area where you need to boost the signal. If you use a Yagi exterior antenna, you should normally aim it away from all interior antennas, regardless of separation, to prevent oscillation.

Antenna Aiming



CAUTION: SIGNAL OSCILLATION CAN CAUSE RADIO INTERFERENCE WITH RADIO TOWERS AND RESULT IN CIVIL AND/OR CRIMINAL PENALTIES.

3.5 Locating the BDA

Select an indoor location for the BDA that meets the following criteria:

- Wall or ceiling mounts are both acceptable.
- Near a properly grounded 110VAC outlet.
- Avoid in a tightly enclosed or overly hot spaces.
- All power and warning lights are easily visible.
- You can use the shortest cables to connect all antennas.

3.6 Accessories

The final step in the planning process is to make sure you have all of the necessary accessories to complete the installation. You will need all of the items listed in Chapter 1 of this manual plus some or all of the following:

- Cable clips: Use these to secure the cables to interior and exterior walls/ceilings.
- Appropriately rated sealant/caulking: Use this to waterproof the opening where the cable from the exterior antenna enters the building, if needed.
- Hand and/or power tools: As needed to complete the installation.
- Personal Equipment (PPE): Use all PPE required by local codes and/or best practices to help ensure personal safety during installation.



CAUTION: YOU ARE RESPONSIBLE FOR ENSURING THAT THE INSTALLATION MEETS ALL APPLICABLE CODES.

Note: You may need to obtain a permit from your local building department to install the BDA and antennas. Check your local building and/or electrical codes.

3.7 Need Help?

If you need help planning your installation, contact a qualified installer, the reseller who supplied you with the BDA, or Potter:

Call: 844-626-7638

Email: cs-guardian@pottersignal.com

CHAPTER 4: INSTALLATION

4.1 Soft Installation

Perform a “soft” installation of all components to test signal coverage and oscillation before making the installation permanent. Avoid making holes or other permanent attachments during this phase. Refer to Chapter 5 for configuration and testing instructions. Proceed with final installation once configuration and testing are complete.

4.2 Exterior Antenna

Mount the exterior antenna in the location you selected when planning. Follow all of the instructions included with the antenna to ensure that your installation is done properly. Here are a few reminders and essential steps:

- An omnidirectional antenna is always mounted vertically.
- A Yagi antenna is mounted horizontally, and aimed at the desired radio tower (line of sight).
- Mount the antenna.
- Connect a length of cable to the antenna and tighten until hand-tight.
- Run the cable along the planned route.
- Install a properly grounded LP lightning protector.
- Seal any holes you make in the outside of the building with caulking or sealant.



WARNING: FAILURE TO EXERCISE CAUTION WHEN WORKING IN HIGH AREAS COULD CAUSE A FALL AND PERSONAL INJURY.



WARNING: DO NOT TOUCH ANY LIVE ELECTRICAL WIRES OR ALLOW THE ANTENNA OR CABLING TO TOUCH ANY LIVE ELECTRICAL WIRES.



CAUTION: AVOID AIMING A YAGI ANTENNA TOWARD ANY INTERIOR ANTENNA.

4.3 Interior Antennas

Mount the interior antenna(s) in the location(s) you selected when planning. Follow all instructions included with the antenna(s) to ensure the installation(s) are done properly.

Here are a few reminders and essential steps:

- Dome antennas are mounted on the ceiling as close to the center of the desired coverage area as possible, domed (convex) side pointing down.
- Flat panel antennas should be wall-mounted as close as possible to the center of the wall, or at one end of long narrow space.
- Mount the antenna.
- Connect a length of cable to the antenna and tighten until hand-tight.
- If you are installing multiple antennas, run the cable to the splitter location and connect the cable to one of the outputs on the splitter.
- Connect another length of cable to the input side of the splitter (if used) and run this cable to the BDA location.
- It is important to keep the cable runs equal or use taps to ensure a harmonious install.



CAUTION: VERIFY THAT ALL INTERIOR ANTENNAS MEET THE SEPARATION REQUIREMENTS DESCRIBED IN THE PREVIOUS CHAPTER, AND THAT NO ANTENNA IS AIMED TOWARD THE EXTERIOR ANTENNA.



CAUTION: DO NOT CONNECT AN INTERIOR ANTENNA TO THE SPLITTER INPUT.

4.4 Mounting the BDA

Mount the Guardian QR700-G2 as follows:

- Verify that the selected location meets all criteria described in the previous chapter.
- Mount a 24-inch x 24-inch x 3/4 inch thick sheet of plywood on top of sheetrock, secured into wall studs where the NEMA housing is to be placed. The plywood should be flush against wall.
- Once the plywood is secure, attach the NEMA housing to the plywood base using the screws provided. In most installations, the housing will be oriented so the I/O ports are facing down.
- Connect the outdoor antenna cable to the signal booster connector port marked OUTSIDE and tighten the connection.
- Connect the indoor antenna cable to the signal booster connector port marked INSIDE and tighten the connection.



CAUTION: DO NOT POWER ON THE BDA UNTIL INSTRUCTED TO DO SO.



CAUTION: NEVER POWER ON THE BDA WHEN ANY ANTENNAS ARE DISCONNECTED AS THIS COULD DAMAGE THE BDA.

CHAPTER 5: CONFIGURATION & TESTING

5.1 Powering on the BDA

1. Make sure the exterior and interior antenna cables are firmly connected to their corresponding ports on the NEMA-4 enclosure.
2. Plug a surge suppressor into a grounded 110VAC wall outlet.
3. Plug the AC end of the power adapter (supplied with your BDA) into the surge suppressor.
4. Plug the DC end of the power adapter into the Power port on the NEMA enclosure.
5. Verify that the green Power light is illuminated.
6. When the booster is turned on, the band lights will flash red and yellow for approximately 10 seconds.



CAUTION: ONLY USE THE POWER SUPPLY INCLUDED WITH THE BDA. USE OF ANOTHER POWER SUPPLY COULD DAMAGE THE BDA AND/OR POWER SUPPLY.




CAUTION: DO NOT PROCEED BEYOND THIS POINT UNTIL THE BDA IS POWERED ON AND NO RED WARNING LIGHTS ARE ILLUMINATED.

5.2 DIP Switch Configuration

By default, your booster ships with all DIP switches turned OFF to provide maximum gain in all channels. This should always be your starting point whenever installing or reinstalling the booster. When the booster is turned on, the band lights will flash red and yellow for approximately 10 seconds. The following diagrams and notes explain how to interpret, and use, these switch banks.

DIP switch organization


- PS 700 DL DIP switches control 700 band downlink
- PS UL DIP switches control 700 band uplink



Switches should be OFF unless red flashing lights occur for a channel or channels. Red flashing lights indicate the system has detected oscillation for the corresponding channel(s). They then turn off if adjustments are not made. When adjusting the booster, full power is not always the best option. Your goal is to obtain a usable signal in as many areas of the building as possible.


Configuration and Testing

Switch 1	Switch 2	Switch 3	Switch 4	Switch 5
1 dB	2 dB	4 dB	8 dB	16 dB



Additive combination effects:

- Switch 1 (1 dB) + Switch 2 (2 dB) = 3 dB attenuation
- Switch 1 (1 dB) + Switch 2 (2 dB) + Switch 3 (4 dB) = 7 dB attenuation
- Switch 1 (1 dB) + Switch 2 (2 dB) + Switch 3 (4 dB) + Switch 4 (8 dB) = 15 dB attenuation
- Switch 1 (1 dB) + Switch 2 (2 dB) + Switch 3 (4 dB) + Switch 4 (8 dB) + Switch 5 (16 dB) = 31 dB attenuation
- Turning all switches OFF = 0 dB attenuation (booster is at full gain).
- Turning ON switch #1 in a bank = 1 dB attenuation (booster maximum gain is reduced by 1 dB).
- Turning ON switches #1, 3, and 5 in a bank = 1+4+16 dB attenuation = 21 dB attenuation. For example, in an 80 dB booster, the selected channel is reduced to 59 dB (80 dB -21 dB).
- Turning ON all switches in a bank = 1+2+4+8+16 dB attenuation = 31 dB attenuation. For example, in an 80 dB booster, the selected channel is reduced to 49 dB (80 dB-31 dB).



When the BDA is powered on, the green Power Light (2) should illuminate.

- If any of the bands are oscillating, the band light (1) will flash red and will eventually shut down if adjustments are not made.


Note: In general, the uplink and downlink DIP switches should be set identically but this is not always the case.

5.3 Band LED Conditions

This section will help you interpret the LED indicators on your Guardian QR700-G2. But first, here are a few configuration and testing points to keep in mind:

- When choosing a location for the outside antenna, a minimum signal reading of -100 dB is needed. A signal in the -70 dB to -90 dB range is recommended for best performance. A signal stronger than -70 dB may cause the affected frequency bands to stop amplifying.
- The booster gain dials should be at maximum level unless the control light for a specific frequency band is flashing red or red-yellow. In either case, try increasing the antenna separation between the inside and outside antennas as much as possible first, and then restarting the booster.
- Avoid setting the gain below 35 dB, as this could cause the affected frequency band to stop amplifying.

LED INDICATIONS



LED Color	LED Condition	Resolution
Yellow	Solid	The frequency band is not in use. Eventually, the band will enter sleep mode. When the light is off, it means things are normal, and that the band is active.
Yellow	Flashing	The Automatic Gain Control (AGC) is self-adjusting. This occurs during normal operation.
Red	Flashing	The booster is receiving too much signal. Can cause the affected band to automatically turn off. If this happens: 1. For kits using an OMNI outside antenna, relocate the outside antenna to a location where the signal is weaker. 2. For kits using a YAGI outside antenna, turn the antenna in short increments away from the signal source. 3. Increase the separation between antennas (more vertical separation works best). 4. Add an inline attenuator to the cable connected to the Outside port on the booster.
Red	Solid	The associated frequency band is off. If the red light flashes for a long time (caused by too much signal), and then turns solid red, it means the associated frequency band has been turned off. This will happen if the gain dial for that frequency band has been turned all the way down.
Yellow/ Red	Flashes alternating colors	Self-oscillation has been prevented. Try this: 1. Increase the separation between the inside and outside antennas. If your booster kit uses two directional antennas (example: outside Yagi antenna and inside panel antenna), ensure that they are facing away from each other. 2. If the condition continues, lower the dB gain setting in small increments until the light turns off or flashes yellow.

Refer to your Sentry Monitoring Software for more information about LED codes. Meanwhile, if you have any questions during setup, please reach out to our U.S.-based support technicians:

Call: 844-626-7638

Email: cs-guardian@pottersignal.com

5.4 Testing & Troubleshooting

Once the booster is powered on (and no Warning lights are on), walk around the area to assess the voice and/or data signal in representative variety of locations. Refine the antenna locations and/or gain levels as needed, and then complete the permanent installation when confident the system will perform well.

Please note:


- It is unrealistic to expect full reception everywhere in the building.
- Generally, increasing gain by 6dB doubles the coverage distance of the interior antennas. Start at the lowest gain and increase gradually as needed.
- If one or more red Warning lights comes on, it indicates there is oscillation in that band and adjustments are needed.
- If coverage is unable to be reasonably well-balanced, an additional interior antenna and/or a different type of interior antenna may need to be installed, and/or the interior antennas may need to be relocated.

CHAPTER 6: ALARM INTERFACE, DEFINITIONS & CONDITIONS

6.1 Summary Alarm Trigger Conditions


The Summary Alarm (pin 4 and pin 7) is triggered under one (or more) of the following conditions:

- PA shutdown causing by oscillation
- PA shutdown causing by RF Power overload
- Repeater power OFF
- Repeater current is abnormal



Relay Shown In Non-Alarm Condition

Dry Contact RF Module Summary in Non-Alarm
Relay connection Fig. in Non-Alarm Condition
Contacts pins4 of A2, pins7 of A2 CLOSE



Relay Shown In Alarm Condition

Dry Contact RF Module Summary in Alarm
Relay connection Fig. in Alarm Condition and Power OFF
Contacts pins4 of A2, pins7 of A2 OPEN


Load Restrictions

Alarm Dry Contact Output Restrictions

- Maximum switching voltage: 125 VAC, 60 VDC
- Maximum switching current: 1A


External Alarm Input Restrictions

- Maximum repetitive reverse voltage: 28 V
- Impedance load: 470 Ohm



Relay Shown In Non-Alarm Condition

Dry Contact VSWR in Non-Alarm
Relay connection Fig. in Non-Alarm Condition
Contacts pins3 of A2, pins6 of A2 CLOSE



Relay Shown In Alarm Condition

Dry Contact VSWR in Alarm
Relay connection Fig. in Alarm Condition
Contacts pins3 of A2, pins6 of A2 OPEN

6.2 Alarm LED Descriptions

	Status	Description	Note
POWER	Green ON	Normal	
	OFF	Missing Power	
ALARM1	Red ON	NO	Reserved for: Battery under-voltage Power AC off Battery charge
	OFF	Normal	
ALARM2	Red ON	RF Module Summary: Over-current Osc alarm Over-power	
	OFF	Normal	
ALARM3	Red ON	VSWR Alarm	
	OFF	Normal	

CHAPTER 7: SENTRY CONFIGURATION & MONITORING

7.1 Sentry Software Introduction

Potter's Sentry is a revolutionary advancement in signal-booster management. It aids in the installation, optimization, and ongoing management of your Guardian QR700-G2 BDA. It provides installers with tools for seamless system configurations, and it helps pinpoint malfunctions due to unforeseen changes in the amplifier landscape, such as new towers or repeater systems. Sentry also notifies installers or end users about various parameters via email. Features include:

- Quick notification about booster changes and over-power situations.
- Allows offsite monitoring and adjustments related to booster performance, such as uplink, downlink or bands.
- Helps optimize installations by monitoring and identifying the strongest signal strength available.

7.2 Software Installation



To install and configure the server, follow these steps:

- Get the Potter Sentry software from the device supplier, or download the software here: www.pottersignal.com/ERCES
- Install the software using the steps outlined below.
- Configure the server to a static IP or public IP address.
- In order to function on the network correctly, the server and the Guardian QR700-G2 device must be (a) on the same Local Area Network, or (b) the server must be the front end to the device.
- Use appropriate security software for safe and reliable operation when connected to a network.
- All device and user information will be stored on the computer.


Double-click Sentry (.exe or .zip) to start the installation of the most recently published Sentry software, which takes the user to a Welcome screen similar to the one shown on the following page.

Note: To avoid install glitches, Potter recommends closing all other Windows programs running on the designated computer before proceeding.


After all other programs have been shut down, click Next, which will take you to the User Information screen shown on the following page. This is where user information may be entered. This may be the installer, or a different personnel member who will be monitoring the system on an ongoing basis.

The image shows the 'FMClient Setup' window with a 'User Information' title. The window has a blue gradient background at the top and a white area below. The text reads: 'Enter your user information and click Next to continue.' Below this, there are two text input fields. The first is labeled 'Name:' and contains the text 'Potter'. The second is labeled 'Company:' and also contains the text 'Potter'. At the bottom, there are three buttons: '< Back', 'Next >' (which is highlighted with a blue dashed border), and 'Cancel'.

When you have completed the fields, click Next to proceed to the Installation Folder screen as shown on the next page. In most situations, the default choices and information provided here work fine. Click Next to continue.



The above screen confirms the installation folder and shortcut folder where you can access the Sentry software. Click Next to proceed with the installation. The software will now install. A launch icon will be placed on your Desktop. When the process is complete, you'll should see the Installation Successful screen as shown below. This verifies that the Sentry Remote Server software installation is complete.



Click Finish. Your Sentry installation is done. Proceed to the next section, Hardware Installation.

7.3 Hardware Installation

Once the Sentry software is installed, you can proceed to connect and configure the Guardian QR700-G2 BDA.


To install the hardware, first complete the following steps:

- **USB Connection.** Use a USB cable to connect your computer directly to the Guardian QR700-G2 USB port. The USB connection on the Guardian QR700-G2 is accessible by opening the NEMA-4 enclosure. The port is on top of the unit inside the enclosure, as shown below.
- **Ethernet Connection.** Plug the Ethernet cable into the yellow-capped socket on the bottom of the NEMA-4 enclosure, labeled Ethernet. The other end of the Ethernet cable goes to the network server or network switch on the LAN.


Once the connections are made, power on the Guardian QR700-G2 BDA.

Register an account: Before you install the hardware, you'll first need to register an account. Connect your computer to the network where the Guardian QR700-G2 Ethernet connection was made. A secure LAN connection is important because it will allow the computer to "see" the Guardian QR700-G2 device on the network.


Start the Sentry client application by clicking on the shortcut that resulted from installing the software. You will see the screen below:




Sentry Configuration & Monitoring




Click Register and you'll see the following screen, prompting you to enter the local Server IP address.



Enter the local Server IP, or you can use Potter's server IP address: 12.232.138.150.



Enter a User Name, Password, E-mail, and User Phone in the fields provided. Then click Register to proceed. You will the Login screen again, as shown in the next screen.




In the fields provided, enter the Username and Password that you just registered on the system. This will enable you to proceed to device configuration, as explained in the steps below:

Register the Device. Connect the Guardian QR700-G2 device to the networked client computer with a USB cable as described in the previous section. Make sure the server is also linked to the computer. Select a serial port and click Open, as shown in the Add Booster screen below.

Complete device registration as described below:

- Click Refresh to query device parameters



- Enter a name in the Booster Name field
- Enter the location in the Location Address field (optional)
- Click Add to register the device on the server
- Keep in mind that only the registered user is authorized to see/operate the added device.

Using the same screen as before, configure the device according to the steps below.

7.4 Configuring the Booster System

Configure the Device.

- Select a serial port and click Open.
- Click Refresh to query device parameters.
- Click on the drop-down menu and select a server IP address and port number to make sure the device can be connected to the server.
- Dynamic IP is available by checking Auto Search IP function, OR...
- ...OR enter IP parameters manually, if the device needs a static IP.
- Click Apply to finish the configuration.

Add Booster (one booster per Sentry)

Com Port: COM3

☐ IP Mode ☒ Domain name Mode

Domain Name: erces.tower-iq.com

Server Port: 5210

☒ Auto Search IP

Sentry IP: 10. 0. 5. 34

Sentry Subnet Mask: 255.255.254. 0

Sentry Default Gateway: 10. 0. 4. 1

MAC Address: 12-05-24-10-52-43

Refresh Apply

Sentry ID Code: 83FF8D50E4E4538303446034

Booster Name: Booster 1

Location Address:

Add

The following summary screen appears if the booster connects to the server successfully:

Sentry Remote Monitoring and Control System(V2.84)

Tools: Add Booster Create Folder

Type: GuardianCA Name: Guardian CA Address:

Band	Channel	Attenuation	Manual Attenuation	Automatic Gain Control Attenuation	Gain	Output Power	Outside Signal Strength	Uplink/Downlink Status	Band On/Off	Over Power	Oscillation	Manual Shut Off	Operation Power	Current Status
PS700	Uplink 798-806M	0 dB	0 dB	0 dB	80 dB	-4 dBm		Active	ON	Normal	Normal	Normal	3.6 W	Normal
	Downlink 768-776M	0 dB	0 dB	0 dB	80 dB	-79 dBm		ON	ON	Normal	Normal	Normal	3.9 W	Normal

Sentry Software Version: PT Guardian V2.0.0

Device Status: Normal Outdoor Antenna: Normal Indoor Antenna: Normal

In1 Alarm: Normal In2 Alarm: Normal

Refresh Apply

Server Address: 192.168.1.100 UserName: tester LoginTime: 2013-01-01 00:20:27

00:22 2013/1/1 星期二

Column Definitions:

- Attenuation: Manually adjusted attenuation via software.
- Manual Attenuation: Manually adjusted attenuation using controls on the device.
- Automatic Gain Control: Automatically adjusted attenuation from excessive signal.
- Gain: Current gain.
- Output Power: Current power.
- Outside Signal Strength: Strength of input signal.
- Uplink/Downlink Status: RF band status: Sleep, Active, OFF.
- Over Power: Over-power alert status: Red=Alert; Green=Normal.
- Oscillation: Oscillation-alert status: Red=Alert; Green=Normal.
- Over Attenuation: Manual over-attenuation status: Red=Alert; Green=Normal.
- Current Status: Over-current alert status: Red=Alert; Green=Normal.
- Operation Power: Single RF band power.

Other Definitions:

- Booster Connection: Booster and Sentry module Connection. Red=Disconnection; Green=Normal.
- Sum Power: Sum power of the device
- Device Status: RF status of the device. Red=Alert; Green=Normal.
- Uplink VSWR: Uplink VSWR status. Red=Alert; Green=Normal.
- Inside antenna VSWR status. Red=Alert; Green=Normal.
- Battery Connection: Battery connection status. Red=Disconnection; Green=Normal (reserved function).
- Battery Capacity: Battery capacity status. Red=Low; Green=Normal (reserved function).
- AC Power: AC-power status. Red=Off; Green=Normal (reserved function)
- Battery Charger: Battery charging status. Red=Charging; Green: Normal (reserved function)
- Out1 Alarm, Out2 Alarm: Out-alert status. Red=Alert; Green=Normal.



NOTE: BOTH THE MANUALLY ADJUSTED ATTENUATION BY DEVICE AND BY SOFTWARE CANNOT EXCEED 25 DB.

Another feature is E-mail Alert, meaning that the user will receive an e-mail if an alert occurs.

Modify Booster Information. To modify the booster information, right click to access a pop-up menu with the following additional options. Select Edit Booster Info to proceed.

Edit Booster Info
Delete Booster
Antenna Position Debug
Reboot Sentry
Restore Default Settings

Edit booster info

Sentry ID Code

83FF8D50E4E4538303446034

Sentry MAC Address

12-05-24-10-52-43

Sentry Software Version

PT GuardianQR V2.0.0

Booster Software Version

PT_Guardin2QR_V1.0.0

Booster Name


Demo Room

Location Address

Edit


Delete Booster. To delete a booster, right click on the summary screen again to access a pop-up menu with additional options, and then select Delete Booster.

You will see a confirmation screen as shown below. Click Yes to proceed.



Password and E-mail Management:

In the Tools pull-down menu, you can change your account information, including your password, or the e-mail address for status reports. Roll over the Accounts heading and click on Modify Password/E-mail to access this feature.



To modify your password, type in the requested information shown below and click on Modify.

Modify Password/E-mail

User Name

Potter

Old Password

New Password

Confirm Password

Old E-mail

arTom@pottersignal.com

New E-mail

Modify

Modify

To change the e-mail address where alerts go, enter a new e-mail as shown above and click on Modify.



NOTE: IF YOU FORGET YOUR PASSWORD, CLICK FORGOT MY
PASSWORD ON THE LOGIN PAGE.
THE PASSWORD WILL BE SENT TO YOUR E-MAIL ADDRESS.

CHAPTER 8: SAFETY AND COMPLIANCE

8.1 IC Compliance

This is a Class A device. The product has also been tested and found to comply with the Industry Canada (IC) RF Exposure Requirements, pursuant to IC RSS-131.

Industry Canada ICES-003 Compliance Label: CAN ICES-3 (A)/NMB-3(A)

The Manufacturer's rated output power of this equipment is for single carrier operation. For situations when multiple carrier signals are present, the rating would have to be reduced by 3.5 dB, especially where the output signal is re-radiated and can cause interference to adjacent band users.

This power reduction is to be by means of input power or gain reduction and not by an attenuator at the output of the device.

La puissance de sortie nominale indiquée par le fabricant pour cet appareil concerne son fonctionnement avec porteuse unique. Pour des appareils avec porteuses multiples, on doit réduire la valeur nominale de 3,5 dB, surtout si le signal de sortie est retransmis et qu'il peut causer du brouillage aux utilisateurs de bandes adjacentes. Une telle réduction doit porter sur la puissance d'entrée ou sur le gain, et ne doit pas se faire au moyen d'un atténuateur raccordé à la sortie du dispositif.



CAUTION: Unplug cord before disconnecting from unit.

ATTENTION: Débranchez le cordon avant de vous déconnecter de l'appareil.

RF Exposure Warning (IC)

In order to comply with the IC RF exposure requirements, the antenna installation must comply with the following:

For 2 dBi gain antenna: The antenna must be installed so as to provide a minimum separation distance of at least 32.5 cm (~12.8 inches) between the antenna connected to the RF booster and the human user's body within the area. (VSWR $\leq$ 2:1, $Z_o = 50$ ohms and a cable attenuation less than 1 dB). For 8.5 dBi gain antenna: The antenna must be installed so as to provide a minimum separation distance of at least 68.7 cm (~27.1 inches) between the antenna connected to the RF booster and the human user's body within the area. (VSWR $\leq$ 2:1, $Z_o = 50$ ohms and a cable attenuation less than 1 dB).

8.2 A Word About Safety

Follow all safety precautions in this manual. This information is designed to prevent personal injury, equipment malfunction, and/or radio interference. You are responsible for ensuring a safe installation.

Your installation may require working in high locations such as roofs and/or ladders. Follow applicable safety regulations and best practices to avoid falling. Take care not to drop objects from any high area. Cordon off ground areas directly below the section of roof you are working on, or below your ladder whenever possible.

In addition, as a qualified installer, you are responsible for knowing and following all applicable codes and regulations and for obtaining all required permits and inspections.

Always use appropriate personal protective equipment such as goggles, gloves, hard hat, etc. as needed, and as required.



WARNING: FAILURE TO EXERSICE CAUTION WHEN WORKING IN HIGH AREAS COULD CAUSE A FALL AND PERSONAL INJURY

Product Name	Guardian QR700
Uplink Frequency Range (MHz):	798-806
Downlink Frequency Range (MHz):	768-776
Maximum Gain:	80 dB
Gain Adjustment:	25 dB
Input / Output Impedance	50 Ω
Noise Figure:	≤ 8 dB
VSWR:	≤ 2.0
Supported Standards:	Public Safety 700
AC/DC Input:	110 VAC, 2.1A, 60 Hz, +24VDC, 3A Standby
Maximum RF Output Power:	27 dBm Downlink / 24 dBm Uplink
P1dB:	31.5 dBm
RF Connectors:	N Female (both ends)
Power Consumption:	30W
Operating Temperature:	-4° F to +131° F
Dimensions:	21.5 x 17 x 6 inches
Weight:	49.6 lbs.
IC:	7784A-QR700

CW (Sinusoid Signals)

Frequency (MHz)	Bandwidth (MHz)	Mean Power (dBm)	Gain (dB)
Uplink: 798-806	17.68	25.8	74.8
Downlink: 768-776	17.17	28.2	80.2

*Input power level is decreased before reaching AGC -0.5 dB to maintain compliance with the intermodulation product of -13 dBm.
Mean power: Measurements obtained on section 6.2 where Pmean = P01+3dB

CHAPTER 10: WARRANTY

Activate your product warranty at pottersignal.com/ERCES

For questions regarding your warranty, contact a Potter representative at 844-626-7638 or email cs-guardian@pottersignal.com

10.1 Warranty Periods

Your warranty includes the following periods:

- **Three-Year Product Warranty:** Potter products are covered under a three-year product warranty from the date of purchase. This protects the customer from any defects or problems the product may have that are solely the fault of Potter. Incorrect installation or misuse will void this warranty. Upon the return of a defective product, Potter will issue the customer a working replacement. All returned packages should contain all products distributed.
- **Five-Year Extended Product Warranty:** A five year warranty is available for purchase on any products sold by Potter. A five-year warranty must be obtained at the time of purchase. This warranty adds an additional two years to the three year warranty we provide. All regulations still apply.

10.2 Three-Year Product Warranty

Potter warrants its products for three years from the date of purchase against defects in workmanship and/or materials. Specifications are subject to change. The three-year warranty only applies to products meeting the latest IC Certification Guidelines. A two-year warranty applies to any products manufactured before May 1, 2014.

Products returned by customers must be in their original, un-modified condition, shipped in the original or protective packaging with proof-of-purchase documentation enclosed, and a Return Merchandise Authorization (RMA) number printed clearly on the outside of the shipping container.

Buyers may obtain an RMA number for warranty returns by calling the Potter Return Department toll-free at 844-626-7638. Any returns received by Potter without an RMA number clearly printed on the outside of the shipping container will be returned to sender. In order to receive full credit for signal boosters, all accessories originally included in the signal booster box must be returned with the signal booster. (The Buyer does not need to include accessories sold in addition to the signal booster, such as antennas or cables.)

This warranty does not apply to any product determined by Potter to have been subjected to misuse, abuse, neglect, or mishandling that alters or damages the product's physical or electronic properties.

Potter warrants to the Buyer that each of its products, when shipped, will be free from defects in material and workmanship, and will perform in full accordance with applicable specifications. The limit of liability under this warranty is, at Potter's option, to repair or replace any product or part thereof which was purchased up to THREE YEARS after May 1, 2014 or TWO YEARS for products purchased before May 1, 2014, as determined by examination by Potter, prove defective in material and/or workmanship. Warranty returns must first be authorized in writing by Potter. Disassembly of any Potter product by anyone other than an authorized representative of Potter voids this warranty in its entirety. Potter reserves the right to make changes in any of its products without incurring any obligation to make the same changes on previously delivered products.

As a condition to the warranties provided for herein, the Buyer will prepay the shipping charges for all products returned to Potter for repair, and Potter will pay the return shipping with the exception of products returned from outside the United States, in which case the Buyer will pay the shipping charges.

The Buyer will pay the cost of inspecting and testing any goods returned under the warranty or otherwise, which are found to meet the applicable specifications or which are not defective or not covered by this warranty.

Products sold by Potter shall not be considered defective or non-conforming to the Buyer's order if they satisfactorily fulfill the performance requirements that were published in the product specification literature, or in accordance with samples provided by Potter. This warranty shall not apply to any products or parts thereof which have been subject to accident, negligence, alteration, abuse, or misuse. Potter makes no warranty whatsoever in respect to accessories or parts not supplied by it.

10.3 Limitations of Warranty, Damages and Liability

EXCEPT AS EXPRESSLY SET FORTH HEREIN, THERE ARE NO WARRANTIES, CONDITIONS, GUARANTEES, OR REPRESENTATIONS AS TO MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHER WARRANTIES, CONDITIONS, GUARANTEES, OR REPRESENTATIONS, WHETHER EXPRESSED OR IMPLIED, IN LAW OR IN FACT, ORAL OR IN WRITING.

Potter AGGREGATE LIABILITY IN DAMAGES OR OTHERWISE SHALL NOT EXCEED THE PAYMENT, IF ANY, RECEIVED BY CELLPHONE-MATE, INC. FOR THE UNIT OF PRODUCT OR SERVICE FURNISHED OR TO BE FURNISHED, AS THE CASE MAY BE, WHICH IS THE SUBJECT OF CLAIM OR DISPUTE. IN NO EVENT SHALL Potter BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, HOWSOEVER CAUSED.

All matters regarding this warranty shall be interpreted in accordance with the laws of the State of California, and any controversy that cannot be settled directly shall be settled by arbitration in California in accordance with the rules then prevailing of the American Arbitration Association, and judgment upon the award rendered may be entered in any court having jurisdiction thereof. If one or more provisions provided herein are held to be invalid or unenforceable under applicable law, then such provision shall be ineffective and excluded to the extent of such invalidity or unenforceability without affecting in any way the remaining provisions hereof.

WARNING: E911 location information may not be provided or may be inaccurate for calls served BY USING THIS DEVICE.

1609 Park 370 Place
Hazelwood, MO 63042
844.626.7638
www.pottersignal.com/ERCES

Potter has made a good faith effort to ensure the accuracy of the information in this document and disclaims the implied warranties of merchantability and fitness for

Warranty

a particular purpose and makes no express warranties, except as may be stated in its written agreement with and for its customers. Potter shall not be held liable to anyone for any indirect, special or consequential damages due to omissions or errors. The information and specifications in this document are subject to change without notice.

© 2022. All Rights Reserved. All trademarks and registered trademarks are the property of their respective owners.