
BAR CODE
BAR CODE
POWER
ALARM
FIRE-MILEAGE
MILEAGE
EARTH FAULT
SUPERVISORY
SILENCED
TROUBLE
SILENCE
RESET
ACK
DRILL
1
2
3
4
5
6
7
8
9
ENTER
0
ESC
TROUBLE
SUPERVISORY
ALARM
BATTERY
NAC 1
NAC 2
NAC3
NAC4
NAC5
NAC6
P-LINK1
P-LINK2
SLC
PGM
XMIT 1
XMIT 2
AUX IN
AUX OUT
PORT 1
PORT 2