



*MIC Corrosion Inside Pipe*

This test is designed to conform to the requirements of NFPA 25, 2002, 13.2.1.2 requiring testing for MIC if slime or tubercles are discovered in an internal inspection. The test involves removing some of the slime, deposit, scale, tubercles, mounds, etc. from the pipe section at Potter for microbiologically influenced corrosion (MIC) analysis.

The pipe section will be evaluated for wall loss and MIC damage.

Upon receiving the sample, the lab will establish a chain of custody and prepare the sample for bacterium extraction. Five groups of bacteria will be cultured: Heterotrophic Bacterium which determines if the majority of bacterium are anaerobic (without air) or aerobic (with air) in nature; Slime Forming Bacterium (aids in tubercle formation); Iron Related Bacterium (iron-pipe oxidizing and reducing bacterium); Sulfate Reducing Bacterium (causes pit corrosion) and Acid producing Bacterium (causes pit corrosion). The testing will take approximately 9 days to allow for bacteria culture growth. A full written report will be provided approximately 15 business days after testing is started.

**Pipe Section Return Procedure**

**Note:** The sample must be received by Potter within 72 hrs after it is removed from the sprinkler system.

1. Package the failed pipe section (8” – 24” in length) to preserve deposits and corrosion sites during shipping. Taping plastic bags or duct tape over the ends will help retain deposits during shipping. Mark the sample with system orientation, i.e. top, bottom, if known. Package the pipe section in a shipping box using packing materials to ensure the sample is well-cushioned to prevent being crushed or broken during shipping.
2. Complete sample identification of this document and include with pipe section return.
3. Contact Potter at 800-325-3936 for prepaid shipping information.

**Certification**

Bacterium testing procedures have been tested against the appropriate A.T.C.C. (American Type Culture Collection) strains for each specific group of bacterium.

Includes:

- Sample identification form
- Prepaid shipping - (U.S. Only)
- Laboratory analysis of returned pipe sample

Stock number: 1119184

**Sample Identification**

**NOTE:** This section *MUST* be filled out completely and returned with the sample.

**Person/Firm Requesting Test**

Name: \_\_\_\_\_  
 Company: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_  
 Phone #: \_\_\_\_\_  
 Email: \_\_\_\_\_  
 (If you would like report sent via email)

**Facility Pipe Sample Taken**

Name: \_\_\_\_\_  
 Bldg #: \_\_\_\_\_ Riser #: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_  
 Phone #: \_\_\_\_\_

**System Information**

System (*circle one*): Wet/Dry FPS Age: \_\_\_\_\_ Total # of Risers: \_\_\_\_\_  
 Facility Sq. Ft. (*approx.*): \_\_\_\_\_ # of Floors: \_\_\_\_\_  
 Facility Type: \_\_\_\_\_  
 Type of Pipe (*circle*): TW/Sch 40/Black/Galv/Threaded/Grooved/CPVC  
 Previous System Treatment: \_\_\_\_\_

**Water Sample Information**

Date sample collected: \_\_\_\_\_ Time: \_\_\_\_\_  
 Location in system where obtained: \_\_\_\_\_  
 Sample collected by: \_\_\_\_\_  
 Company: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 Sample description/remarks: \_\_\_\_\_  
 \_\_\_\_\_